KEYENCE



Adapter for GP-M Series Precautionary Points When Installing

Symbols

NOTICE It indicates a situation which, if not avoided, could result in product damage as well as property damage.

Installation method

NOTICE Always use the O-Ring included with the sensor unit.			
1	Fit the O-Ring included with the sensor unit to the groove in the adapter as in the diagram on the right.	GP-M001/M010/M025	GP-M100/M250/M400
	When using the G1/4 Female convertible adapter (OP-87283), attach the O-Ring included with the OP-87283 to the groove of the piping connection part (the G1/4 screw portion) of the adapter.	(OP-87287) Adapter	(OP-87288) Adapter
2	Connecting the sensor unit/adapter/piping After installation, the body may be rotated horizontally to 330°. When rotating, hold the clasp in place with something such as a wrench.	O-Ring	ain unit ng the OP-87281)
_	Throttle (OP-87311/87312)		

Throttle (OP-87311/87312)

For adapters other than the cheese adapter (OP-87286/87644), a separately sold throttle (Minimum width ø0.5 mm) to lessen vibration and surge pressure can be installed. Especially for the GP-M100/M250/M400, installation of the throttle is recommended.

- OP-87311 (Corresponding adapter: OP-87280/87281/87282/87284/87285) is installed to the sensor unit installation part (G3/4 female screw).
- **OP-87312** Corresponding adapter: OP-87283) is installed to the piping installation part (G1/4 female screw). Install each with a flathead screwdriver. (Recommended tightening torque: 1.2 N•m)

Common precautionary points

- The recommended tightening torque when installing an adapter to the Sensor unit is 20 N•m. It is recommended to apply grease to the G3/4 male screw part of the sensor main unit to prevent scorching.
- If the O-Ring is damaged it is possible that liquid will leak, therefore please purchase the following optional attachment.
 O-Ring for the GP-M001/M010/M025: OP-87287
 O-Ring set for the GP-M100/M250/M400: OP-87288
 G1/4 female adapter (OP-87283) piping side O-Ring: OP-87310
- When replacing the O-Ring, ensure that there is no debris on the surface to come in contact with the O-Ring.